



STEP 1 GETTING READY

IMPORTANT: AMBIENT TEMPERATURES MUST BE GREATER THAN 50°F (10°C) FOR PROPER INSTALL!

IMPORTANT: DO NOT ALLOW SECURITY FILM TO BECOME PINCHED OR CREASED

Clean the surface and all edges of the windshield thoroughly before applying film. This can be done with clean water or any non-alcohol solution. After this is done, clean it again! Keep the area and film free from dirt, debris, or any contaminants. Wash your hands thoroughly before handling the film then always keep them saturated/wet during the install to prevent permanent fingerprints in the adhesive.

Installation Solution: Water, with a few drops of a non-abrasive Soap, and 1oz of Isopropyl Alcohol

STEP 2 THE HARD PART

After the windshield is thoroughly clean, liberally spray the solution onto the windshield. The film installs exactly like window tint or vinyl graphics. The film should slide or float into place.

Then gently remove the clear liner from the security film. An extra pair of hands will make this part of the installation easier. You may also need to spray some of the solution onto the film to alleviate any static build-up.

Once the liner is removed, then gently position and tack the security film onto the windshield. Once it is tacked on, liberally spray the outside of the film with the solution. This will provide a lubrication layer to help the squeegee more easily glide over the film.

Then use the squeegee to press down the film, squeezing the water out from underneath the film. The best method while doing this is to start in the center and squeegee the water out to the edges. You may use towels to help absorb the moisture that collects at the edges.

IMPORTANT: A BLOW DRYER OR HEAT GUN MAY BE NEEDED TO HELP SOFTEN THE FILM TO ASSIST IN MOLDING TO THE CURVATURE OF THE WINDSCREEN AND ELIMINATING ANY WRINKLES (FINGERS).

After the film has been squeegeed and the film applied, there may still be some moisture at the edges. You can use the blow dryer to help accelerate the evaporating process.

STEP 3 TRIM IT UP

To cut the excess film. Use an X-acto knife or breakaway blade to cut the film. Use the edge of the windshield to guide your knife and hand. This will allow for a smooth, clean, & consistent incision.

After trimming and removing the excess film, run a towel along the edges to firmly apply any remaining film down.

STEP 4 HOLDING OUT

IMPORTANT: ALLOW 24 HOURS FOR FILM TO COMPLETELY DRY BEFORE DRIVING OR WASHING CAR.

The curing time for complete moisture/condensation evaporation varies with temperature and sunlight exposure. Any trapped moisture will evaporate over time. If any large excess spots of installation solution are found trapped underneath the film, can be either pushed to the edge (if close enough), or released with sewing needle.

To maintain the film, you should wash weekly and wax every few months.

If you have any problems or questions during the installation, please contact us at install@lamin-x.com or 706.955.0677